



Recovery Tracks KDREC2PTRKA Usage Guide

Product Features

- 3.5 tonne weight capacity
- UV stabilized coating
- Tie down points

Instructions

1. Lower your tyre pressures.
2. Dig out sand, mud or snow from in front of your tyres and underbody.
3. Place the tracks under your tyres as much as possible, in the direction you will be driving.
4. Make sure all people are standing well clear of the vehicle.
5. Slowly drive onto the tracks and out of the sand, mud or snow in low gear.
6. Do not spin your wheels! If the wheels are not gripping onto the tracks, reposition the tracks.
7. Do not ever use the tracks as a bridge.

If you have any further questions or concerns regarding the use of this product, please contact the Kogan.com customer support team.