

# KROMO

## Wall Mounting Instructions

### Plaster Wall Installations

#### Mark the mount position on the plaster wall

Ensure that your installations are away from power points, and are set so that any hanging towels or other items won't touch the floor. Using a stud finder, locate where the wall studs are. Mark their positions with a pencil, then place your Kromo product against the wall and mark the first mounting point in line with the stud.

#### Screw mounting brackets into wall

Screw the mounting bracket into the wall. If you need a secondary mounting point (such as with a towel rail), mark out the second point on the wall based on the product length. Use a spirit level to make sure that the mounting brackets will be at the same height. In the event that the secondary mounting point is not located over a wall stud, you can reinforce the mount with a nylon wall plug before screwing the mounting bracket into place.

### Tile Wall Installations

#### Mark the mount position on the tile wall

Once you have located the point that you wish to install the mount, place a piece of masking tape over the point and mark the exact spot with a pencil. The masking tape will help the drill stay in place, keeping it from slipping on the tile glaze.

#### Selecting your drill bit

The selection of the drill bit is important. You will need to consider the hardness of the material you are drilling through. In many cases a carbide drill bit will do the job, however most hardware stores will have "glass and ceramic spade bits", as well as "diamond" bits.

Ensure that you use the correct drill bit sizes to match the anchor plugs you are installing. It is always preferable for the whole to be slightly too small, as you can always shave a bit off the anchor.

#### Drilling

Place the tip of the drill bit on the mark you made on the masking tape, then drill slowly into the tile. It is preferable to select a point away from the edge of the tile, as you are more likely to shatter or chip the tile when drilling near the edge.

Do not drill too quickly, or you may overheat your drill. If you are using a hammer-drill, ensure that you are NOT using the hammer function. You may find it helps to spray a mist of water onto the drill hole while you are drilling (if you are using a diamond drill bit, this is essential).

#### Anchor

Push the screw anchors into each drilled hole to firmly secure the screws inside the tile. You may then mount the Kromo accessory.

If you have any further questions, please contact the Kogan.com customer support team or speak to an expert at a hardware store.