




OWNER'S MANUAL

Convair Tower Heater CTH08



(English) (CTH08)

convair[®]

SAFETY

General Safety

Please read these instructions before using the heater and keep for future reference.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction in using the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance. Do not poke anything through the ventilating slits.

Always use the heater in an upright position. Stand it on a firm, solid, horizontal base (not on thick pile carpets).



WARNING: In order to avoid overheating, do not cover the heater.

Leave nothing hanging above or in front of the heater (e.g. clothes, curtains, bedding, fabrics). Be sure that the back panel vent slots on the heater are uncovered otherwise it will overheat. Clean these openings at regular intervals to prevent airflow reduction (refer Maintenance section).

The heater surfaces are hot when in use. To avoid burns, keep bare skin away from the top ventilation outlets. Leave plenty of room around the heater.

Do not use this heater outdoors, or on wet surfaces. Do not use the heater near flammable areas or substances.

Electrical Safety

Connect the heater to a single 230 Vac, 10A socket only. Do not plug into double adaptors or multi-outlet power boards. Do not use an extension cord to operate this heater.

Make sure that the heater never comes into contact with water. Never position the heater under a power outlet.

Never turn the heater on if the power supply cord is damaged or if the heater's casing is obviously damaged. If the power supply cord is damaged it must be replaced by the manufacturer, a service agent or similarly qualified persons in order to avoid a hazard.

Do not pull the heater along by the power cord or place the cord near the heater's surfaces. Always uncoil the power cord completely before use. Use of extension cords is not recommended.

Do not use this heater in the immediate surroundings of a bath, a shower or a swimming pool. If the heater is to be used in a bathroom, ensure that switches and other controls cannot be touched by a person in the bath or shower.

Do not use this heater with a programmer, timer, separate remote-control system or any other device that switches the heater on automatically, since a fire risk exists if the heater is covered or positioned incorrectly.

Always turn the heater off and unplug from the power socket when not in use.

Safety Device

To avoid overheating problems the inbuilt safety device will interrupt electricity in the event of the heater overheating.


If this should happen:

- Check that the heater is positioned correctly, not close to any furnishings.
- See that there is no dust or other obstacles blocking the vent slots.
- Clean the vent slots if necessary.

The heater is also equipped with a 'tip-over' switch, which will turn off power to the heater elements if it should fall over.

ASSEMBLY

COMPONENTS LIST



1. Control panel
2. Display Panel
3. Body sensor
4. Front Grille
5. Handle
6. Remote holder
7. Air inlet grille
8. Power Isolation Switch
9. Base (Locking nut not shown)
10. Mains power cord
11. Remote control

ASSEMBLY

Unpack the heater components and check that you have all of the components.

Turn the heater upside down and remove the plastic Locking nut. Assemble the Base onto the heater and lock into position with the Locking nut.

Note: Ensure the nut is tight to avoid shaking of the heater.

REMOTE


When the heater power is on, the remote control can be used to operate the heater from up to 4m away.

If there are two or more heaters within this distance all will be operated by the same remote control.

Replacing the battery

Release battery slide by pressing on the tab at the bottom of the remote. Remove the battery and replace with an equivalent CR2032 type battery.


Note: Your remote control will be supplied with a battery.




OPERATION

DISPLAY


Control Panel



Display Panel Indicators



Remote Control



OPERATION

Ensure the heater is plugged into a mains power outlet and is switched on.

Turn the isolation switch on (I), at the back of the heater, to begin use. The heater will make a 'beep' and the power indicator on the display panel will become lit.

The control panel or the remote control can be used to operate the heater, except for ECO mode, which is exclusively on the control panel.

OPERATION CONT.

Turning on/off

Press the ON/OFF button, on the heater or remote, to turn the heater on. The heater will start in the last operating mode used.

To turn the heater off press the ON/OFF button.

Note! The fan will continue to run for a further ten (10) seconds, after the heater is turned off.

Heat settings

The heat setting can be switched between low heat (1700W) and high heat (2400W) by pressing the HEAT button.

Swing function

The heater can be set to oscillate from side to side to better distribute heat within the room. Press the SWING button to turn swing mode on & off. The swing indicator on the display panel will be lit when swing mode is on.

Temperature control

The heater has an option to control the room temperature to a set point. The temperature can be set to 14°C, 18°, 22°C or 26°C.

When the room temperature exceeds the set temperature the heater will turn off. When the room temperature drops 2°C below the set temperature the heater will resume heating.

Set the temperature control by pressing the TEMP button. The indicators on the display panel will show the temperature selected.

If no indicators are lit then temperature control is not selected, and the heater will continuously operate.

CLEANING AND STORING

OPERATION CONT.

ECO mode

ECO mode will automatically adjust the heat setting (low and high) of the heater according to the room temperature. Refer to table below for operating logic:

Room Temperature	Heat Setting
TR < 18°C	High heat
18 °C < TR < 22°C	Low Heat
22°C > TR°C	Off

Note! Heat and temperature control settings cannot be adjusted in ECO mode.

Body sensor

In body sensor mode the heater is looking to detect humans in the room. If a human body is not detected the heater will turn off after two (2) minutes. The body sensor indicator will flash when the heater has switched off. Heating will immediately resume when a human is sensed.

Note! Body sensor mode does not operate when oscillation mode is selected.

Body sensor mode can be cancelled anytime by pressing the body sensor button until the light on the display panel goes out.

Note! ECO mode will not work when the body sensor is active.

Timer

A timer can be set to automatically switch the heater off after a set period of time. To set, press the TIMER button once to set to the time to one (1) hour, press twice to set to two (2) hours, press three times to set to four (4) hours and press four times to set to eight (8) hours.

The timer indicators on the display panel will show the selected time.

Cancel the a timer by pressing the TIMER button until no lights are lit or by turning the heater off.

Make sure that the device is switched off before cleaning.

Wipe the surface of the heater by using a clean damp cloth.

Do not use chemical liquids when cleaning the heater.

Do not submerge the heater in water.

Make sure that the heater has cooled down completely before storing. Storing in its original packaging is highly recommended.



Waste electrical products must not be disposed of with household waste. This product should be taken to your local recycling centre for safe treatment.

WARRANTY

In this warranty:

We or **us** means Seeley International Pty Ltd. ABN 23 054 687 035, and our contact details are set out at the end of this warranty;

You means you, the original end-user purchaser of the Goods;

Supplier means the authorised distributor or retailer of the Goods that sold you the Goods in Australia; and

Goods means the product, unit, appliance or equipment which was accompanied by this warranty and purchased in Australia.

Our Goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the Goods repaired or replaced if the Goods fail to be of acceptable quality and the failure does not amount to a major failure.

In addition to any rights and remedies that You may have under the Australian Consumer Law or any other law, subject to the terms of this warranty, We provide the following warranty:

1. If, during the first 24 months from the date of first retail purchase (**Warranty Period**), the Goods upon examination prove defective by reason of improper workmanship or material, We will replace the Goods or any part thereof without charge. We may substitute with any similar Goods (including a panel heater, or a portable heating product of a different size or shape), even if it is not on our current price/equipment list. Alternatively, we may arrange a refund of the purchase price you paid.
2. We are under no obligation to replace the Goods under clause 1 if the Goods have not been used only for personal, domestic or household purposes and have not been installed/mounted (if relevant), operated, and maintained in accordance with the instructions in the Owner's Manual. The addition of any third party device or the removal or the alteration of any of our components will void this warranty. In addition, the warranty granted under clause 1 does not apply to:
 - Adjustments necessary due to misuse of the appliance,
 - Normal user maintenance,
 - Setting of controls,
 - Transit damage, or
 - Damage caused by user misuse, tampering, or failure to observe the care and special provisions in the instructions.
3. The warranty granted under clause 1 is limited to replacement only. As far as the law permits, We will not be liable for any consequential loss suffered through, or resulting from, the non operation, or ineffective operation of the Goods. The warranty granted under clause 1 does not cover damage to the Goods or other loss resulting from acts of God.
4. No other person, firm or corporation is authorised by us to offer or give on our behalf any other or greater warranty than that given under this warranty. The benefits conferred by this warranty are in favour of You and any person deriving title to the Goods through or under such person and are intended to be separate from and additional to all other rights and remedies that they may have in law in respect of the Goods.
5. We are not responsible in any way for any failure and/or inadequate performance of the Goods which arises from or is connected to the use in the Goods of non-genuine spare parts. We strongly recommend that only spare parts supplied or approved by us are used in the Goods.
6. In order to claim under the warranty granted under clause 1 You must within the Warranty Period return the Goods to the Supplier at the place of purchase together with the proof of purchase.
7. Alternatively, you may claim under the warranty granted under clause 1 by within the Warranty Period returning the Goods to us at the address below together with: (i) a covering letter which states your name and address, daytime telephone number, and model and serial number of the goods, (ii) the legible and unmodified proof of purchase, which clearly indicates the name and address of the original retailer, the date and place of purchase,

WARRANTY CONT.

and the product name or other product serial number, and (iii) a copy of the completed Warranty Information below.

8. This warranty does not cover the cost of claiming under the warranty, it is your responsibility to cover all forwarding and freight costs incurred in returning the Goods to the Supplier at the place of purchase or us.

9. This warranty is only valid and enforceable in Australia.

Our liability under this warranty is limited to the extent permitted by law. That is, to the extent that it is fair and reasonable, if the Goods are not of a kind ordinarily acquired for personal, domestic or household use or consumption, your remedies associated with any failure or defect of the Product will be limited to:

- (a) the replacement of the Goods or the supply of equivalent goods;
- (b) the repair of the Goods;
- (c) the payment of the cost of replacing the Goods or of acquiring equivalent goods; or
- (d) the payment of the cost of having the Goods repaired and subject to the terms and conditions included in this warranty.

For technical assistance before returning the product please contact:

1300 650 399

Please retain your receipt as proof of purchase. Every request for warranty must be accompanied by proof of purchase.

Complete the following for your records:

Serial Number _____
Product Convair Tower Heater
Model: CTH08
Purchased from _____
Date purchased _____

You can also register your warranty with us on our website.

Service Department

Seeley International Pty Ltd

112 O'Sullivan Beach Road

Lonsdale, South Australia 5160

Technical assistance in Australia: 1300 650 399

Website: www.seeleyinternational.com

PRIVACY NOTICE

Seeley International Pty Ltd ABN 23 054 687 035 will use the personal information you provide us with to provide warranty support for the product you have purchased and to inform you about other products and services. If you choose not to supply us with the information requested, we may be unable to provide you with warranty support. We may also disclose your information to third parties, such as related entities; retailers, distributors, service agents and contractors who are affiliated with us; or marketing or market research companies. If you would prefer not to receive direct marketing communications from us, please follow the instructions to "unsubscribe" which will be included in the direct marketing communications we send you, or contact our Privacy Officer using the details set out below. While we do not currently transfer personal information to overseas recipients or store personal information overseas, if we transfer your information to third parties who do so, we will take reasonable steps to ensure that the overseas recipients do not breach the *Australian Privacy Principles*. By registering your warranty, you consent to having your personal information used in this way. Please read our Privacy Policy on our website www.seeleyinternational.com for further explanation of how we collect, use, hold and disclose personal information, and how you may access and seek correction of your information. It also sets out how you may complain about a breach of the Australian Privacy Principles, and how we will deal with your complaint. You may contact us at: Privacy Officer, Seeley International Pty Ltd, 112 O'Sullivan Beach Road, Lonsdale, South Australia 5160.

It is the policy of Seeley International to introduce continual product improvement.
Accordingly, specifications are subject to change without notice.
Please consult with your dealer to confirm the specifications of the model selected.



Warranty Service
Australia 1-300-650-399
seeleyinternational.com

convair®