










ERGOLUX


ELEAMMSHBBKH ELEAMMSHBWHH

Parts List

 Ax5	 Bx1	 Cx1
 Dx1	 Ex1	 Fx1(L&R)
 M8x40m Gx6	 Hx6	 M6 Ix1

Please lay all components out on a clean floor to ensure that all parts have been correctly supplied. If you find any pieces are missing, please check all packaging thoroughly, then contact the Kogan customer support team.

Assembly



If you have any questions regarding the assembly or usage of this product, please contact the Kogan customer support team.