



ERGOLUX

ELEAMMSLBBKH

Parts List



Ax5



Bx1




Cx1




Dx1




Ex1



Fx1 (L&R)



M8x40m
Gx6



Hx6




M6

Ix1

Please lay all components out on a clean floor to ensure that all parts have been correctly supplied. If you find any pieces are missing, please check all packaging thoroughly, then contact the Kogan customer support team.

Assembly



If you have any questions regarding the assembly or usage of this product, please contact the Kogan customer support team.