



HOTSHOT RECLINER GAMING CHAIR


ELHSGACBRA, ELHSGACBBA, ELHSGAMCBKA, ELHSGAMCBGA & ELHSGAMCPWA

COMPONENTS


Lay all components out on a clean floor and ensure all parts are included. If any pieces are missing, check all packaging thoroughly, then contact help.Kogan.com for assistance.




A




B




C




D



E (x1 pair)



F



G



H M8x55 (x2)




I M8x25 (x2)




J M6x20 (x4)



K (x2)



L




M




N

ASSEMBLY


Step 1:




Step 2:




Step 3:




Step 4:



Step 5:



Step 6:



Need more information?

We hope that this user guide has given you the assistance needed for a simple set-up. For the most up-to-date guide for your product, as well as any additional assistance you may require, head online to **help.kogan.com**

kogan.com