











ERGOLUX

ELPADPULBBKH

ELPADPULBWHH


Parts List

 Ax5	 Bx1	 Cx1
 Dx1	 Ex1	 Fx1(L&R)
 M6x55m Gx2	 M6x50m Hx4	 Ix6
 M6 Jx1		


Please lay all components out on a clean floor to ensure that all parts have been correctly supplied. If you find any pieces are missing, please check all packaging thoroughly, then contact the Kogan customer support team.

Assembly


1




2




3



4



5



6



If you have any questions regarding the assembly or usage of this product, please contact the Kogan customer support team.