


# ESTELLE

## Premium Ionic Hair Straightening Brush ESIONHRBRSA

Before use, please read the user manual carefully. Keep a copy handy for future reference.

### Features

- Fast, safe PTC heating component operation
- Tourmaline ceramic interlayer heating plate
- Negative ions to protect hair from damage
- 3 temperature settings (150/170/190°C)
- 360 degree swivel cord with hanging loop
- Rated voltage: AC 100-240V 50/60Hz
- Rated power: 30W



## Attention

Please handle this product with care and inspect it regularly to ensure it is in good working order.

If the product, power supply cord or plug shows any signs of damage: stop use, unplug and contact [Kogan.com](http://Kogan.com) support.

# Operating Instructions

Before using this product, make sure you have read and understood the entire contents of the safety instructions. Before use, the hair must be washed and dried to ensure that the hair will style correctly.

In the event of the head of the brush heating up and being used close to areas where it can come into contact with your skin (such as your neck or shoulder), you can use a towel to create a protective barrier.

- Plug the brush into the power socket. The indicator light will light up blue to indicate it is working.
- Hold down the power source/temperature down button for 3 seconds to enable the negative ion function. The display screen will flash and show “150”.
- According to your hair quality, press “temperature +” or “power source / temperature -” to adjust the temperature for use. You can choose between 150°C, 170°C or 190°C.
- While heating up, the screen will flash. Once the brush has reached the desired temperature, the screen light will light up and remain lit.
- During use, hold the brush ONLY by the handle, paying attention to maintaining a safe distance between the heated device and your skin/eyes etc.
- Part the hair evenly and tightly during use, combing from the roots to the ends of your hair. Keep doing this until the desired look has been achieved.
- After use, please turn the brush off and unplug it from the power. Lay the product out in an open, dry location to allow it to cool down.
- After 30 minutes of use, the unit will automatically go into energy-saving mode. When this occurs, the heating and negative ion function will turn down and the display screen will show “---”. Press any button to return the unit into working mode if you wish to continue using it.
- The product has an anti-burning feature to protect the unit if the core reaches temperatures in excess of 65°C. The display will show “HOT” and you should unplug the unit and allow it to sit and cool down.

Due to the different environments between a home and a factory testing environment, there may be slight differences between real temperatures and the setting temperatures.

## **Safety Warnings**

- Do not use this product near water.
- Do not use this product in the bath or shower.
- After use, unplug the brush from the power socket (even if it is already turned off).
- If any damage or wear is seen on the power cord, it must be replaced by a Kogan.com technician or a qualified electrician.
- Please do not insert any metal objects into the product, as this can result in damage to the product or an electric shock.
- Do not use this product for any function other than it's intended purpose.
- When the product is connected to the power supply, do not leave it unattended, and make sure to unplug it again after use.
- Do not use any accessories or attachments that are not supplied by Kogan.com. The use of such accessories may lead to product failure and will void your warranty.
- During use, or during the cooling down period, do not leave the product on any surfaces that may be damaged by the heat (including the radiating heat).
- Avoid coming into direct contact with the hot elements with your bare skin.
- This product is not intended for use by children or people with mental or physical disabilities unless there is a guardian who can help them.
- Please ensure the product has cooled down sufficiently before storage.
- After use, do not wrap the power cord around the product; instead coil the power cord loosely by the side of the appliance.
- Product packaging should be discarded or kept in a location where infants and children can play with them.

If you have any further questions or concerns regarding the use of this product, please contact the Kogan.com customer support team.