




Sportsbuds FSBTSPEPGREA / FSBTSPEPBLKA Quick Start Guide

Product Layout

	Left Side	Right Side
	1 - Earhook	6 - Protective Outer Casing
	2 - Volume Down/Previous Track	7 - Microphone 1
	3 - Volume Up/Next Track	8 - LED Light
	4 - MF Button (Multifunction Button)	9 - Microphone 2
	5 - Speaker	10 - ON/OFF Switch
	12 - Sliding Cable Cinch	11 - Charging Contact (microUSB)


Charging Battery

1. Plug the USB charging cable into the headset.
2. Plug the other end of the USB charging cable into the charger with a USB port, or into your PC.
3. The red indicator on the headset will light up.
4. When the battery is fully charged, the red indicator will turn off and the blue indicator will turn on.
The charging process takes approximately 2 hours.

When Battery Is Low

The red indicator light will flash when the battery is low. At the same time, you will hear a voice prompt indicating that the battery is low. At this time, the headset should be charged.

The battery meter will also be displayed on iPhones and other iOS devices, as seen to the right.



IMPORTANT NOTES:

- For the first time usage, please charge the headset fully before use.
- You must recharge the headset if it has not been used for more than 12 months.
- Make sure that the headset is fully charged for at least 4 hours before initial use.

Usage

Multifunction Button

Pairing, Answer / End / Reject / Transfer Calls, Voicing Dialling, Redial, Play/Pause Music

Turning Headset ON/OFF

To turn the headset on, slide the ON/OFF switch down. The blue LED light will flash with a voice prompt. The headset is now turned on.

To turn the headset off, slide the ON/OFF switch up. The red LED light will flash with a voice prompt. The headset is not turned off.

Pairing the Headset

You are required to pair the headset with your mobile phone once before using it.

1. Turn on the headset. The red and blue LED lights will flash alternately after about 6 seconds, signifying that the unit has gone into pairing mode if there is no other previously paired/connected devices within range.
2. Activate Bluetooth mode on your mobile phone.
3. Set your phone to discover to find "Fortis Sportsbuds", and follow the instructions.
4. If your phone asks for a passkey or PIN code, confirm with "0000" (4 zeroes).
5. When the phone and headset are paired and connected, you will hear a voice prompt.

Notes:

- If the headset is not in pairing mode, your mobile phone will not find the headset. Please set the headset into pairing mode before making your mobile phone search for Bluetooth connections. You can manually turn the headset into pairing mode by pressing and holding the MF button for 2 seconds when the headset is on.
- If no pairing is possible for a period of time (approximately 2 minutes), the headset will automatically leaving pairing mode and go into idle mode. The blue indicator will turn to red and will flash.

Pairing the Headset with a Second Mobile Phone

The headset supports Multipoint Technology, which means that it can be paired and connected to two Bluetooth-enabled mobile phones for use at the same time.

1. Pair and connect your headset to your first mobile phone (see "**Pairing the Headset**").
2. Turn off the headset.
3. Turn off the bluetooth function on the first mobile phone.
4. Turn the headset back on and it will go into pairing mode automatically, as long as there are no other paired/connected devices in range.
5. Pair the second mobile phone to the headset as described previously. Turn off the headset once the connection has been completed.
6. Turn the headset back on one Bluetooth has been re-enabled on the first mobile phone. The headset will be automatically connected to both mobile phones.

IMPORTANT: If you need to pair the headset with only one mobile phone, turn off the Multipoint feature. This will avoid the possible audio disruption that may occur at the beginning of music playing. This audio disruption can last for up to 20 seconds.

Turning Multipoint Function ON

When the headset is on and not connected to any device, quickly press V+ and V- at the same time to turn multipoint functionality on.

Turning Multipoint Function OFF

When the headset is on and not connected to any device, press and hold V+ and V- at the same time for 3 seconds to turn multipoint functionality off.

Making Calls

Once the headset is successfully paired and connected with your mobile phone, you can use it to make and receive calls. The headset can be used with voice dialling if your mobile phone supports this function. Please consult with your mobile phone's user manual for more information.

- **Voice Dialling**
Double click the MF button, wait for the voice prompt, then say the name of the person you wish to call.

- **Using Phone Keys to Call**
Enter and dial the number on the mobile phone as you normally do. Once the call has been set up, the sound will be transmitted to your headset automatically.
- **Redial**
Press and hold the MF button for 2 seconds to redial the last number called.

Answering / Ending / Rejecting Calls

When the headset is turned on and there is an incoming call, you will hear a musical tone.

- Press the MF button once to answer the call.
- Press the MF button once to end the call.
- Press and hold the MF button for 2 seconds to reject the call.

Caller ID Reading

The headset supports reading the caller's phone number when a call is incoming.

Putting Call on Hold

- Press and hold the MF button for 2 seconds to put the current call on hold and accept the incoming call from call waiting.
- Press and hold the MF button for 2 seconds to resume to the first call.
- Quickly press the MF button to end the current call, then transfer back to the other call automatically.

Transferring Calls

During both incoming calls and outgoing calls, you can quickly press the MF button twice to transfer the call to the mobile phone. If you want to transfer the call back to the headset, quickly press the MF button twice again. Some mobile phones may require a confirmation action.

Adjusting Volume

Volume Up: Hold down V+. You will hear a voice prompt when it reaches highest volume.

Volume Down: Hold down V-. You will hear a voice prompt when it reaches lowest volume.

Mute / Unmute

During a call, quickly press V+ and V- together at the same time to mute the call. Press both again quickly to unmute the call.

Play / Pause Music

Quickly press the MF button to play or pause the music.

Next / Previous Song

Quickly press V+ to skip to the next song.

Quickly press V- to jump back to the previous song.

Connecting to PC or PDA

If your PC or PDA is Bluetooth-enabled you can connect to the headset. Please follow your PC/PDA user manual for connection instructions.

Language Selection

The headset comes with voice prompts in either English or Chinese. You can switch between the two languages by pressing V- once the headset is turned on and not connected to any devices.

Factory Reset

To perform a factory reset, ensure that the headset is not connected to any devices. Then press and hold the MF button for about 5 seconds. The blue and red LED will light up at the same time for about 2 seconds with 2 beeps. This signals that a factory reset has been successful.

Safety Warnings

Permanent hearing loss may result from long-term exposure to sound at high volumes. Use as low volume as possible and avoid prolonged use of the earphones at excessive sound pressure levels. Please read the safety guidelines below prior to using the headset.

Prior to Use

1. Turn headphones on, then adjust the volume control to its lowest possible level.
2. Put headphones on, then slowly adjust the volume up to a comfortable level.

During Use

- Keep the volume at the lowest possible level.
- If increased volume is necessary, adjust the volume control upwards slowly.
- If you experience discomfort or ringing in your ears, immediately discontinue use. With continued use at high volumes, your ears may become accustomed to the sound levels, which may result in permanent damage to your hearing without any noticeable discomfort.

Safety Information

- Stay alert at all times during use! Be aware of your surroundings, especially when crossing roads, train crossings, tram lines or other locations where your safety may be put at risk due to not being able to hear ambient sounds.
- If you have a cardiac pacemaker or other electrical medical equipment, you should consult with your doctor before using this product.
- This product contains small parts that may be hazardous to children. Keep out of reach of small children.
- Never attempt to disassemble the product yourself or push other objects into the device. This may cause a short-circuit which may lead to fire or electric shock.
- There are no user-serviceable parts in this product.
- If the product overheats, is damaged or gets dropped into liquid, discontinue use.

If you have any questions or concerns regarding the use of this product, please contact the Kogan.com customer support team.