



# Kogan Noise Cancelling Headphones KAANCHP65HB Quick Start Guide


## Table of Contents

Safety & Warnings.....	1
Overview.....	2
Bluetooth.....	2
Simultaneous Bluetooth Connection.....	3
Wired connection.....	3
Noise Cancellation.....	3
Charging.....	3
Troubleshooting.....	3

## Safety & Warnings

- Read all instructions before using the product and retain for reference.
- If you have a cardiac pacemaker or other electronic medical equipment, you should consult your physician before using this product.
- This product contains small parts and packaging which may pose a choking hazard. Keep out of reach of children.
- This appliance is designed for consumer use: follow directions and use only as described.
- Always drive safely, avoid distractions and follow required laws.
- Permanent hearing loss may result from long-term exposure to sound at high volumes. Always set the volume to as low a level as possible. Adjust slowly if increasing volume is required. Avoid using earphones for extended periods of time.
- If you experience discomfort or ringing in your ears, stop use immediately. With continued use at high volume, your ears may become accustomed to the sound level, which may result in permanent damage without noticeable discomfort.
- This appliance contains no user-serviceable parts. If it suffers any failure or damage, cease usage and contact Kogan Support after consulting the Troubleshooting section of this manual.

## Overview



1	Volume+ / Next	Press to raise volume. Press and hold to skip to next track. Power On/Off: Press and hold for 3s.
2	Multi-function Button	Phone Call Control: Press to answer/hang up. Press and hold to reject call. Double click to activate Siri.
3	Volume- / Back	Press to lower volume. Press and hold to skip to previous track.
4	3.5mm Port	Bluetooth, battery and microphone will switch off when connected.
5	Microphone	In-line microphone.
6	ANC control	Press to turn on/off noise cancellation.
7	Micro-USB Interface	While Micro-USB cable plugged, the charging indicator turns red while charging, turns blue when fully charged.
8	Raised Indicator	The raised indicator on the left headphone can help visually-impaired people distinguish left and right sides.

## Bluetooth

1. Press and hold Multi-function button for 3 seconds to turn headphones on and they will enter pairing mode automatically after approximately 5 seconds: the LED indicator will flash blue and red. (If they are not paired, they will turn off after 5 minutes.)
2. Activate Bluetooth on your device and locate the headphones in the Bluetooth settings menu.
3. If you are prompted for a passcode, enter four zeros (0000). Once successfully paired, the headphone LED indicator will display blue.

## Simultaneous Bluetooth Connection

- After connecting with the first phone, turn off both the headphones and the Bluetooth function on the first phone.
- Turn the headphones on and pair to the second phone.
- On the first phone, turn Bluetooth on and reconnect.

Note: The headphone can connect to two phones, but it will only play audio from one at a time.

## Wired connection

Use the included audio cable to connect. (Bluetooth, battery and microphone will switch off.)

## Noise Cancellation

Press the ANC (Active Noise Cancellation) button to activate noise cancelling and the indicator will turn green. Press one more time to turn off the ANC function, then indicator off.

## Charging

Connect Micro USB cable from headphone charging port and to USB wall charging adapter or computer. The LED indicator will turn red while charging and blue when fully charged.

(The headphones will remind you the battery is low every 15 minutes when the battery power is below 10%.)

## Troubleshooting

Issue	Resolution
Indicator blinking red quickly	<ul style="list-style-type: none"><li>• Low battery - charge headphones</li></ul>
Not turning on	<ul style="list-style-type: none"><li>• Battery depleted - charge headphones before starting</li></ul>
No indicator when charging	<ul style="list-style-type: none"><li>• If the battery has been depleted or has not been turned on for a long time, the charging indicator may take a few minutes to illuminate</li></ul>
No sound over Bluetooth	<ul style="list-style-type: none"><li>• Ensure Bluetooth is switched on and connected.</li><li>• Check sound output is headphones in device Bluetooth settings</li><li>• Ensure distance is within 10 meters.</li><li>• Check for without external interference.</li><li>• Ensure device is not connected to other sound outputs through Bluetooth or headphone jack.</li></ul>
No sound while wired	<ul style="list-style-type: none"><li>• Check the audio cable is inserted correctly and secure</li><li>• Ensure device's headphone jack works correctly.</li></ul>
Cannot connect to Bluetooth	<ul style="list-style-type: none"><li>• Turn headphones off and on again</li><li>• Switch Bluetooth off and on again in device settings</li><li>• Ensure headphone and device's Bluetooth are turned on.</li><li>• Ensure headphones are in Bluetooth pairing mode with indicator illuminated.</li></ul>

User manual is subject to change without notice. For the latest version of your user manual, please visit <https://www.kogan.com/usermanuals/>