



# Portable Waterproof Bluetooth Speaker KABLUWTSPRA Quick Start Guide


## Warnings

It is normal for the speaker to get warm during use or while charging.  
If you need to clean the speaker, please turn it off and disconnect it from all external devices before cleaning.  
Do not use cleaning alcohol or other harsh chemicals to clean the speaker.  
Do not drop or shake the speaker.  
Do not use the speaker in extremely hot or cold environments.  
Do not dismantle the speaker. There are no user serviceable parts inside.

## What's In The Box

Speaker x 1  
AUX cable x 1  
Hook x 1  
USB cable x 1

## Product Diagram



1 - AUX Input	5 - Play/Pause/Handsfree
2 - USB Charging Port	6 - Previous Track/Volume Down
3 - Pairing Switch	7 - Next Track/Volume Up
4 - Mute	8 - Flashlight Switch

# Functions

## Pairing

1. Press the pairing switch. The blue indicator will flash quickly to indicate that the speaker is in pairing mode.
2. Turn the bluetooth functionality of your phone or tablet on and search for "C26", then select it.
3. The speaker will automatically pair to the last paired device when turned on. (Please ensure that the Bluetooth function of your phone is turned on and within range of the speaker.)

## Playing

- Handsfree: when a call comes in, press the Play/Pause/Handsfree button to answer it, or hold the button down to reject the call. Simply press the button again to end the call.
- Redialling: Tap the Play/Pause/Handsfree button twice to redial the last dialled number.
- If you do not wish for the caller to hear you for a period of time during a call, press the Mute button. To unmute the call, press the Mute button again.
- Hold down the Play/Pause/Handsfree button to disconnect the Bluetooth after pairing.
- Hold the Previous Track/Volume Down button to turn down the volume, or press normally to skip back to the previous track. Hold the Next Track/Volume Up button to turn up the volume, or press normally to skip to the next track.

## Flashlight

Press the Flashlight button (whether the speaker is turned on or off) to activate the flashlight function. Hold the Flashlight button down to turn it off.

## AUX Input

Connect the speaker to your phone or other device with the AUX cable provided to enjoy your music via the speaker.

## Charging

When the volume begins to get quieter or distort, it means it is time to charge the speaker. Use the included USB cable to connect the speaker to the computer or an adaptor. The LED indicator will remain red while charging, then it will turn blue once fully charged.

It will take about 5-6 hours to fully charge the speaker via the computer, or 4-5 hours to fully charge it via an adaptor. (We strongly suggest that the speaker is NOT used while charging in order to prolong the battery life.)

## Product Overview

- This speaker should provide you with endless enjoyment while travelling or entertaining outside.
- With the aluminium alloy hook, you can hang the speaker onto a bag or other convenient location.
- With the built-in MIC, you can take a phone call in the car, at home or office.
- If the speaker is left on but with no activity for 10 minutes, it will automatically turn itself off.

## Product Specifications

Bluetooth Module: CSR 4.0

Output Channel: 2.0

Input Voltage: DC-5V/1A

Output Power: 5W x 2 RMS

Battery Specifications: 3.7V/2200MAH

Speaker: 45mm x 2 4AMP/5W

S/N: ?85DB

Size: 186mm (w) x 56mm (d) x 61mm (h)

Weight: 400g

If you have any further concerns regarding the use of this product, please contact the Kogan.com customer support team.