


# kogan

SOBSVŠUT VFĪ OE

## USER MANUAL





## Product Overview

- Transparent tempered glass body. European style. Fashionable and durable.
- No smell, non-toxic and easy to clean.
- Auto power-off after boiling and boil dry protection.
- Just takes 3-6 minutes to boil, with 5 blue indication lights.

## How to Use

- Fill with water, then choose temperature and the option will light up, then press the ON symbol.
- Don't remove the kettle from the base during heating.
- Auto power-off and indicator light goes out after boiling.
- Pick up kettle and pour out desired water.
- Please wait for one minute if you need to reboil, to preserve the lifespan of the heating element.
- Replace the kettle onto the base when not in use. The kettle will not be ON unless the power symbol has been pressed and is highlighted.

## Cleaning & Maintenance

- Please clean the kettle regularly to extend it's service life.
- Make sure the power is OFF before cleaning kettle.
- Don't immerse the unit or the power cord/base in water.
- To clean, put a mix of cleaning detergent/vinegar with water at a 2:1 ratio into the kettle, then turn it on until it boils and turns itself off automatically.
- Keep the mix in the kettle for 24 hours, then pour it out and put clean water into the kettle and turn it on again until it boils.
- The vinegar and lime-scale should be removed when pouring out this water. If the bottom of the kettle still feels like it has lime-scale, please repeat the procedure.
- You may wish to run a few cycles of clean water through the kettle prior to using it for drinking water.

## Safety & Precautions

- Please read instructions prior to using product.
- Please make sure voltage according to the rated power of the kettle. Please contact the Kogan Customer Support team if the power cord is damaged.
- The kettle can only be used with the specific supplied base plate.
- Don't hang the power cord on the edge of the table and don't let it touch other hot items.
- Keep water below the max water mark. Water may erupt when boiling kettle if the water is too close to the top.
- The switch of the kettle is an electrical safety switch. It will auto power-off when no water is inside kettle or water level isn't sufficient.
- Don't immerse kettle in water.
- Please keep kettle away from base plate when pouring out water, putting water in and/or cleaning.
- Throw away the water when using the kettle for the first time, as the first batch of water used may smell strange. Please put 2 teaspoons of soda with water and boil if the smell remains after several cycles of boiling.
- Please disconnect from power sources if the unit will not be used for an extended time.
- Do NOT refill the recently boiled kettle with cold water straight from the tap. The extreme changes in temperature may cause the glass body of the kettle to crack.