



# kogan

## Lightweight Bluetooth Headphones Quick Start Guide

### Product Layout



- |                      |                            |                  |
|----------------------|----------------------------|------------------|
| 1. Previous/Volume + | 2. Power/Answer/Pause/Play | 3. Next/Volume - |
| 4. Micro USB Slot    | 5. MIC                     |                  |

### Product Specifications

- Unit Length: 370mm
- Weight: 45g
- Charging Method: Micro USB
- Battery: 3.7V / 200mAh
- Charging Indicator: Red LED Light
- Charging Time: Less than 2 hours
- Working Time: 5 - 6 hours
- DB Adjustment: 8dB
- Working Temperature: -5 ~ 45°C
- Storage Temperature: -40 ~ 70°C

### Speaker/Mic

- Speaker diameter:  $\Phi 30$ mm
- Impedance: 32 $\Omega$
- S.P.L: 113dB +/- 3dB S.P.L.at 1KHz
- Rated power: 50mW
- Frequency Response: 200HZ-3KHZ
- Microphone Unit:  $\Phi 4 * 1.5$ mm
- S.P.L: -38 +/- 3dB
- Impedance:  $\leq 2.2$ K $\Omega$
- Frequency Response: 30-16,000HZ
- Operating voltage: 4.5V

### Bluetooth

- Bluetooth Chip: CSR8635A04U
- Password: 0000
- Receiving Sensitivity: -90dBm
- Transmission Range (Hz): 2402 - 2480MHz
- Receiving Distance: 10m

# Operations

## **Power On**

Press and hold the power button down until blue LED light illuminates.

## **Power Off**

Press and hold the power button down until red LED light illuminates.

## **Pairing**

While powered off, press and hold the power button until the red and blue LED lights flash in turn with each other. At this time, put your mobilephone or audio device into pairing mode.

## **Answering Calls**

Click the power button to answer an incoming call.

## **Making Calls**

While in Bluetooth mode, dial numbers into your phone directly. The conversation will transfer to the headphones automatically.

## **Ending Calls**

Press the power button during the phone call.

## **Rejecting Phonecall**

Press and hold the power button for 2 seconds while the phone is ringing.

## **Redial Last Number**

Double-click the power button to dial the last phone number in your phone.

## **Volume Control**

While listening to music, press and hold the volume up or volume down buttons to change the music volume.

## **Previous/Next Track**

While listening to music, click the volume up or volume down buttons to skip tracks.

## **Pause/Play**

While listening to music, click the power button to pause music, then click it again to resume playing.

## **LED Light Indications**

### **Charging**

Red LED light is on.

### **Finished Charging**

Blue LED light is off.

### **Pairing Mode**

Red and blue LED lights flash in turn.

### **Low Power**

Red LED light flashes.

**If you have any questions or concerns regarding the use of this product, please contact the Kogan customer support team.**