



**Pro Urban II Bluetooth Headphones
(Midnight Black + Metallic Red)
KAPDJHP25BA & KAPDJHP25RA
Quick Start Guide**

Safety & Warnings

Handle with care and inspect regularly to ensure product is in good working order.

If this product, power supply cord or plug shows any signs of damage: stop use, unplug the product and contact Kogan.com support.

- Read all instructions before using the product and retain for reference.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- This product is designed for consumer use: follow directions and use only as described.
- Do not use with an extension cord unless necessary, and if so, ensure it is suitably rated and it is handled safely as is the product's own power cord:
- Do not allow the power cord to be exposed to water, heat, direct sunlight or overhang where it can be pulled or otherwise be damaged or pose a hazard.
- If you have a cardiac pacemaker or other electronic medical equipment, please consult your physician prior to using this product.
- When using this product, always drive safely, avoid distractions, and follow all required laws.
- Permanent hearing loss may result from long-term exposure to sound at high volumes. Always set volume to a low and comfortable level and adjust upward, slowly, as required.
- This product contains no user-serviceable parts. If it suffers any failure or damage, cease usage and contact Kogan Support after consulting the Troubleshooting section of this manual.

Specifications

Bluetooth Version	5.0	TF/SD Card Support	128Mb-32Gb
Maximum Operation Distance	10m	FM Frequency Response	87.5-108MHz
Transmitting Power	Class 2	Lithium Battery Capacity	1000mAh
Frequency Range	2.402 - 2.480 GHz	Talking Time	30 hours (60% Volume)
Speaker	Ø40mm	Music Playing Time	25 hours (60% Volume)
Impedance	32Ω	Charge Time	2 hours

Product Features

Bluetooth Play - The headphones support Bluetooth pairing with compatible devices to play music.

Hands-free Calls - When connected through Bluetooth, hands-free calling is possible with the built-in microphone.

iOS Battery Display - The earphone's remaining battery is displayed in real-time on compatible iOS devices.

MP3 Play - MP3 files can be played directly from a TF/SD card.





FM Radio - FM Digital stereo radio can be played.

Audio Input - The headphones have a 3.5mm audio input port which allows easy connection to a computer, digital music player, phone, or other compatible device.

Rechargeable Lithium Battery - The built-in rechargeable lithium battery is economical and environmentally friendly.

Intelligent Charging - A voice prompt can be used to charge the battery when low. When fully charged, power input be automatically cut off to ensure no over-charging.

Operation

	<ul style="list-style-type: none"> • Pressing and holding for 3 seconds will power on the device. • When powered on, it will automatically search for a Bluetooth device to which it can connect. • Pressing and holding for another 3 seconds will power off the device. • When listening to music through the TF/SD card or Bluetooth, press this button to pause the music. • When listening to the radio, press this button to prompt a radio channel search (once the search is complete all discovered stations will be saved).
	<ul style="list-style-type: none"> • Volume Up: Press and hold this button to increase volume. • When listening to music through the TF/SD card or Bluetooth, press this button to skip to the next song. • When listening to the radio, press this button to move to the next stored radio station.
	<ul style="list-style-type: none"> • Volume Down: Press and hold this button to decrease volume. • When listening to music through the TF/SD card or Bluetooth, press this button to move back to the previous song. • When listening to the radio, press this button to move to the previous stored radio station.
<p>FM/MP3</p>	<ul style="list-style-type: none"> • Press and hold this button to cycle through the different modes of this device (FM Radio, Bluetooth, TF/SD card). • When listening to music through the TF/SD card or Bluetooth, press this button to choose a mode of music: Natural, Pop, Rock, Jazz, Country, or Heavy Bass.
	<ul style="list-style-type: none"> • When connected to a compatible phone through Bluetooth, press this button to answer a phone call. • Alternatively, press and hold this button to decline the phone call. • During a phone call, press this button to hang up. • Pressing this button two times will redial the last phone number.

Bluetooth Pairing

When first powered on, the headphones will automatically search for a compatible Bluetooth device to which it can connect.

In this mode, a green and blue light will alternatively flash to signify the pairing of the Bluetooth devices.

On your compatible device, select the headphones from the available list of devices.

Upon successful pairing, a 'ding-dong' noise will be played by the headphones and the status indicator light will become blue.

Charging

The headphones can be charged by using the provided Micro USB cable.

Plug the cable into the Micro USB port on the headphones and the other end into a compatible charging adaptor or computer.

When charging, the indicator light will become red.

When the headphones have low battery, they will provide a 'low battery, please charge, please charge' prompt. It will then automatically power off.

If the headphones will not be used for an extended period of time, please charge the headphones to protect the battery and extend battery life.

User manual is subject to change without notice. For the latest version of your user manual, please visit <https://www.kogan.com/usermanuals/>