



KAQIFCSTANDA

Qi Fast Charging Stand

Quick Start Guide



- Micro USB charging port
- Indicator light on front
- Appearance may differ slightly from final product

Safety & Warnings

- Use only the battery, AC charger and accessories supplied by Kogan.com.
- Do not touch the device with wet hands.
- The device can be used in location with an ambient temperature of 0C to 35C. You can store the device at an ambient temperature of -20C to 50C. Using or storing the device outside of the recommended temperature ranges may damage the device or reduce the battery lifespan.
- Magnetic stripe card, including credit cards, phone cards, passports, and boarding passes, may be damaged by magnetic fields.
- This product contains no user-serviceable parts. If the device or power supply suffers any failure or physical damage, cease usage and contact Kogan.com.

Operation

- Before using the charger stand, make sure it is compatible with your device.
1. Connect fast charge compatible AC charger to the charger stand via fast charge micro USB cable. Then, place a supported mobile device on the phone support.
 2. The device will be only fast charging when using a fast charge compatible AC adaptor and a fast charge micro USB cable.
 3. When the mobile device is fully charged, remove the mobile device from the charger stand.
 4. The charger should remain close to the electric socket and easily accessible while charging.
 5. Wireless charging may not work properly if you have attached a thick case to your mobile device. If your case is thick, remove it before placing your mobile device on the charger stand.

User manual is subject to change without notice. For the latest version of your user manual, please visit <https://www.kogan.com/usermanuals/>