



Hammock Chair KDHMKCHRALA Quick Start Guide

Parts List

1 x Hammock Chair

Assembly Instructions

1. Choose a level location and lay out the contents of your hammock and frame. Make sure the hammock is free of tangles and twists.
2. Locate the top ring of the hammock. This will need to be secured by a permanent fixture that can support the maximum weight capacity of the product. A strong rope is recommended but if a hook is used please ensure that the hammock is not able to slide off at any angle.
3. Locate the cushion of the hammock and attach to the two hook and loop straps at the top of the chair. The cushion will then hang forward to provide neck and back support.

Warnings

- These hammocks are portable and are not designed to be permanent structures. Continued exposure to sunlight and/or rain will cause the hammock to deteriorate and weaken.
- Before each use, always check the attachment points are secure and that all ropes are not frayed.
- When entering the hammock, always sit on the hammock in the middle.
- Never try to stand on the hammock.
- Children must be supervised by an adult at all times.
- Avoid wearing shoes or clothing with sharp or protruding objects that may damage or tangle with the hammock.
- At no stage of assembly or use is it necessary to use any excessive force to achieve any of the steps for use. Excessive force will result in damage to the frame or hammock, and this is not covered by warranty.

Please note – due to our policy for continual product development and improvement, specifications and parts may differ from those shown, however the procedures of use will remain the same.

Disassembly

To pack the hammock away, simply reverse the assembly steps.