



Deluxe Double Hammock Stand Combo Quick Start Guide

Parts List

- 2 x Base feet
- 4 x Plastic feet caps
- 1 x Base frame
- 2 x Hammock support frame
- 2 x Hammock attachment hook, curved washer & wing nut set
- 2 x Bolt, nut & washer set to connect Hammock support frames to base frame
- 2 x U bolt, nut & washer set to connect base frame to base feet

Assembly Instructions

1. Choose a level location and lay out the contents of your hammock and frame. Make sure all parts are present and place them side by side for easy identification. Use Figure 1 as a position and component guide for the following steps, taking particular note of the washer position in the order of assembly.
2. Locate the four plastic feet caps and the two base feet. Slide the plastic feet caps over the ends of the base feet, ensuring they are securely in position.
3. Locate the base frame and the two base feet. Connect them together, ensuring the U bolts are securely fastened into position.
4. Locate the two hammock support frames and connect them with the base frame assembly. Ensure the bolts are securely fastened into position.
5. Position the hook into the hole towards the top of the hammock support frame. Select the correct hole appropriate to the hammock size.
6. Position the curved washer and fasten the wing nut to the threaded bolt end of the hook.
7. Attach the hammock to the hook as shown in Figure 2. To check the hook is positioned into the correct hole during step 4, tension the hammock so that when fully loaded, the hammock forms a natural curved shape with the lowest point being a minimum of 40cm above the ground. As the hammock itself stretches, you will need to adjust.




Figure 1




Figure 2

Installation & Warnings

- These hammocks are portable and are not designed to be permanent structures. Continued exposure to sunlight and/or rain will cause the hammock to deteriorate and weaken.
- Before each use, always check the attachment points are secure and that the frame assembly is structurally firm, and that all nuts and bolts are tight and remain tight.
- When entering the hammock, always sit or lie on the hammock in the middle, and never try to stand on the hammock.
- Children must be accompanied by an adult at all times.
- Avoid wearing shoes or clothing with sharp or protruding objects that may damage or tangle with the hammock.
- At no stage of assembly or use is it necessary to use any excessive force to achieve any of the steps for use. Excessive force will result in damage to the frame or hammock, and this is not covered by warranty.

Please note - due to our policy for continual product development and improvement, specifications and parts may differ from those shown, however the procedures of use will remain the same.

Disassembly

To pack the hammock away, simply reverse the assembly steps.