



Pop Up Beach Tent KDPOPBHTNTA Quick Start Guide

Assembly

Step One



Remove from bag and spread tent out on ground.

Step Two



Pull the top rope quickly to open the tent.

Step Three



To pack up, holding the tent firmly at the top, press down gently. The tent should close up easily.

Step Four



Roll tent up again and store safely back in it's tent bag.

If you have any further questions or concerns regarding this product, please contact the Kogan customers support team.