



# Selfie Case for iPhone 6 with Power Bank

## Quick Start Guide

### Important Safety and General Instructions

Read the manual thoroughly before use, even if you are familiar with this type of subject. The safety precautions enclosed herein reduce the risk of fire, shock or damage. Please keep a copy of this user manual in a safe place.

- This LED selfie case is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by a person responsible for their safety.
- Keep the LED selfie case out of reach of children.
- DO not expose the LED selfie case to water, moisture or extreme humidity. Do not use the unit with wet hands.
- Store the LED selfie case at room temperature. Do not expose it to extremely high or low temperatures, or direct sunlight as this may damage the battery or distort the body.
- Ensure the LED selfie case has not been punctured, dropped or taken excessive force.
- Never leave the LED selfie case unattended when in use, including during charging.
- Do not modify, disassemble or attempt to open the LED selfie case.

### Product Overview



1. Function button ON/OFF or Light Modes
2. Case charging indicator
3. Micro USB input port (for charging case)
4. USB output port (for charging phone)
5. LED lights

Note: only use the micro USB cord provided for charging the LED Selfie Case and the original USB charging cord for charging your phone.

### Before First Use

Prior to using the LED Selfie Case, please read all instructions thoroughly. Please ensure you follow all steps before using the device.

1. Unpack the product but keep all packaging material handy until you are sure the case is undamaged and in good working order.
2. Unpack the micro USB charging cable.

**WARNING:** plastic wrapping can be a suffocation hazard for babies or young children.

# Operating Instructions

## 1. How to charge the case

Please use the USB charging cable that is included in the packaging. Connect one end of the cable to the micro USB input port located on the bottom of the LED Selfie Case, then the other end to a USB port on your computer or other suitable USB source. While charging the red LED ambient light behind the button will be on. When the case is fully charged the red LED will go out. Please unplug the case from the charger when fully charged.

## 2. Assembly

Once the LED Selfie Case is fully charged, connect your iPhone\* to the LED Selfie Case by aligning the top edge of your phone with the top groove of the LED Selfie Case. Push down on your phone until it presses firmly into place. To remove your phone, please unattach the phone from the case by starting at the bottom of the case where the charging ports are.

## 3. How It Works

You can control the light modes and light output of the LED Selfie Case with the touch of a button.

### On/Off/Dim

Press once to turn on.  
Press and hold to dim or brighten.  
Press once again to turn off.

### Strobe Effect

Double press to create a strobe effect.  
Double press again for a slow strobe.  
While strobing, press and hold to dim or brighten.

## 4. Charging your phone from the LED Selfie Case

Please use the original USB charging cable that was supplied by the phone manufacturer. Connect the USB end to the USB output port located on the bottom of the LED Selfie Case, then the other end to your phone. While charging, the blue LED light behind the button will turn on.

## FAQ

Problem	Solution
LED lights do not turn on when the on/off button is pressed.	The LED Selfie Case may not have power. Charge the LED Selfie Case following the instructions above.
LED light is not bright.	The LED lights may be set to be dimmed at a lower intensity. Simply hold down the on/off button for at least three seconds and the light intensity should increase.
Is there a correct way to take my phone out of the case?	Yes. Hold the LED Selfie Case with the charging port facing up. Grasp the bottom of the phone with your fingers and gently pull up to lift your phone out.

If you have any further questions or concerns regarding the use of this product, please contact the Kogan.com customer support team.