

WIFI setting

First, the recommended supported model: Wireless network card: module of RT3070 chip

Secondly, WIFI setup:

Connect to the wireless router through the wireless module. The device is accessed through IP. Prior to using this function, the DVR device needs to have access to the Wi-Fi module.

SSID	Authentication	Signal
[Empty]		

Search

Enable	<input checked="" type="checkbox"/>
DHCP Enable	<input type="checkbox"/>
SSID	11n-AP
Password	
IP Address	192 . 168 . 1 . 12
Subnet Mask	255 . 255 . 255 . 0
Gateway	192 . 168 . 1 . 1

OK Cancel Application

【search】: click **【search】** button, Search for wireless devices that are available in the current range;

【enable】: reverse display indicates selection, once selected, settings can be modified;

【SSID】: Wireless LAN name that automatically matches the wireless device you are connected to;

【Password】: Router's wireless network password

【IP address】 : Set the IP address of the device. Default: 0.0.0.0

【Subnet Mask】 : Set the subnet mask of the device. Default: 0.0.0.0

【Gateway】: Set the default gateway of the device, default: 0.0.0