

ovela

Wicker 11 Piece Outdoor Dining Table, Chair and Ottoman Set (Dark Brown) OVWOD11PCBRA

Product Specifications

Table with glass top
Chair with cushion
Ottoman with cushion

Table: 115 x 175 x 74
Chair: 55 x 55 x 68
Ottoman: 47 x 47 x 36

- Synthetic PE Rattan
- Aluminium Frame
- Polyester Cushions
- 5mm Tempered Glass

Care Instructions

- Do not place furniture too close to a heater or air conditioning vent as this may distort the material or surface finish.
- Keep the furniture away from fires and sharp objects, as they may be easily damaged.
- Do not sit on the arms of the sofas and chairs. Avoid standing on a chair or rocking on the back of it, as this may weaken the structure and possibly cause joint failure.
- Always lift furniture carefully when moving it around the home. Never drag it along the floor.
- Do not leave cushions outside in heavy rain. Most outdoor cushions will accept a light soaking, but in heavy rain we recommend you store them inside in the dry.
- Cushions may be washed with a mild solution of soap and water. Rinse thoroughly. Dry completely. Do not use bleach or solvents.
- Rotate cushions regularly to even out the wear and fading.
- Avoid using the glass as a chopping surface or allowing sharp or hard objects come into contact with it as it may result in scratches to the glass.
- Use mats and coasters to protect glass from heat.
- Do not stand or sit on any glass surfaces.
- Use floor protectors on the bottom of furniture (like tables and chairs) to minimise damage to floor coverings.
- Use coasters, place mats, tablecloths and table runners to protect furniture surfaces from heat and stains.