



Dog Training Anti-Bark Collar PPCOLANTBKA Quick Start Guide

Features

- Ideal for calling or training pets.
- Uses vibration instead of static stimulation.
- 2 levels of vibrations and whistles.
- 150 yard range.

Product Specifications

Transmitter specs	Receiver collar specs
Dimensions: 86 x 37 x 16mm	Dimensions: 32 x 55 x 30mm
Weight: 40g	Weight: 75g
Batteries: 1 x 23A 12V battery	Batteries: 2 x 1.5V AAA batteries
Frequency: 433.825MHz	Collar: W 3/4" - - L: 23"
Red light on face	Green light on side
Screw off battery cover and belt clip on back	

The remote controller and receiver of the device apply automatic matching technology. The receiver will make a sound when the batteries are inserted. You can then press any button on the transmitter and the receiver will make a sound, showing that the units are paired and communicating successfully. If the receiver doesn't make any sounds when the batteries are inserted, please remove the batteries and wait for 10 seconds, then try again.

Before using the product

1. Confirm that the batteries have been inserted correctly in both the transmitter and the receiver.
2. Checking the remote controller: Press the buttons on the transmitter respectively. The indicator light should be on. If the indicator light doesn't light up, or is dim, please change the batteries.
3. Checking the receiver: Once activated the receiver should shake. If the receiver has not received any signal for 5 minutes, the power will cut out as a power saving exercise.
4. Connect the collar with the receiver. Adjust the length of the collar so that it fits the neck of your pet. The proper level of tightness should be so that you can fit a finger between the collar and their neck.
5. Press the high frequency and the low frequency vibration buttons on the transmitter in turn. The receiver should give suitable levels of vibration.
6. Press the Sound button on the transmitter and the receiver should make a sound. You can train your pet to perform different tasks according to the tone you play.
7. Press the Light button on the transmitter and the receiver lights should flash. This will come in handy when looking for your pet at night.

Changing batteries

- **Receiver:** Unscrew the two screws in the bottom cover and remove cover. Insert two AAA batteries according to the polarity markings and replace the cover.
- **Transmitter:** Remove the battery cover from the lower back of the transmitter by pushing it according to the arrow, then attach a 12V battery, then replace the battery cover.

Operation instructions

1. Open the buckle of the collar and dress it around the neck of your pet. Adjust the tightness of the collar so that you can fit a finger between the collar and the pet's throat.
2. Pets will most likely feel uncomfortable when the collar is first put on them. At this time, you should NOT use the vibration function on them. Once the pet has become accustomed to the sensation of wearing the collar, you can then move on to using the features of the collar. The high frequency vibration is used to curb improper behaviour in your pet. Do not use this function casually or just for fun.
3. You may use the "weak vibration" to get your dog's attention silently or over long distances.
4. The flashes of light allow you to find your pet at night.
5. When you are not using the product, please remove the receiver from the collar and store it in a safe location without using the vibration features to prolong the life of the battery.
6. If you will not be using the product for a long time, please remove the batteries.

Notes

1. When the collar is put on for the first time, many pets will become agitated. You will need to give your pet some time to become accustomed to it. Do not use the remote during this time.
2. Once powered on, the receiver will be in a standby state. When not in use, be sure to turn the unit off to prolong the life of the battery.
3. Digital and sonic frequencies are used in the remote controller. These signals radiate out from the transmitter, and as such the transmitter does not need to be pointing at the receiver. Large or dense barriers may affect the distance of the transmitter power.
4. Under ideal conditions with no barriers, the transmitter should be able to communicate with the receiver over a distance of 150 metres.
5. The tones of the collar can be used to educate your pet. When depressing the sound key in a rhythm, over time a rhythm can be associated with a particular desired behaviour.
6. The high frequency vibration is to be used to stop improper behaviour in your pet. Each time the high frequency vibration is used, it should not be used for times longer than 30 seconds. Longer usage may result in the unit overheating and unnecessary depletion of battery power.
7. The remote collar is an extremely humane method of pet training. Effective use will enable you to train your pet without causing any pain.
8. Though it is sealed with a damp proof design, do not allow the receiver to be drenched in water. In the event that the collar is immersed in water, allow the unit to thoroughly dry before use.

Please contact the Kogan.com customer support team if you have any questions or concerns about the product.