




## PPFURMBRSHB Fur Remover Brush Set

- Use to clean pet fur and debris from furniture and garments.
- Suitable for use on couches, blankets and other surfaces.


### Safety & Warnings

- Read all instructions before using the appliance and retain for reference.
- Always remove end cap before cleaning the brush.
- Do not use directly on pets.

### Use



1. Brush in the same direction as the arrow to remove pet fur and lint.




2. Slide brush in and out of case to clean brush.

Note: Travel size brush is non-removable: simply extend fully.

### Cleaning & Care

When the case gets full, simply open the end cap on the bottom of the case to remove pet fur.



User manual is subject to change without notice. For the latest version of your user manual, please visit <https://www.kogan.com/usermanuals/>