



Electronic Bug Zapper PTELCINZAPA

Please read carefully and retain a copy for future reference.

Warning

- Do not touch the electric netting.
- Device runs on high voltage. Disconnect the power prior to cleaning or moving.
- NEVER insert metal objects into the grid.
- Do not disassemble the product. There are no user serviceable parts.
- Do not use near explosives or naked flames.
- Do not use near water.
- Do not leave in reach of small children.
- If damaged, the power cord must be replaced by a qualified technician.
- Do not use near water.

Technical Specifications

- Rated Voltage: 220-240V, ~50Hz
- Rated Output: 40W
- Lamp Life: 8000 hours+

Usage

1. Plug the device into a wall socket in the area of use.
2. The ultraviolet lights should glow, which will signal that the device is working.

Changing the Bulb

1. Unplug the unit from the electrical supply.
2. Remove 2 screws from the rear of the unit on the mesh wire.
3. Remove 2 screws from the bottom of the unit on the mesh wire.
4. Pull the mesh wire downwards to gain access to the bulbs.
5. Please note that the bulbs are made of glass. Handle with care.
6. Remove the old bulbs and insert new bulbs.
7. Replace the mesh wire and screws.

Environmental Protection

At the end of its service life, please take the device to your local waste disposal and recycling facility. Do not dispose of electrical products with your household waste.

Attention

Please handle this product with care and inspect it regularly to ensure it is in good working order.

If the product, power supply cord or plug shows any signs of damage: stop use, unplug and contact Kogan.com support.