



Professional Tyre Repair Kit CTTYRRPRKTA Quick Start Guide

Usage

1. The wheel should be removed from the vehicle following the vehicle manufacturer's recommended procedure. Refer to the vehicle manual for information.
2. Inspect the tyre and if possible, remove the object that has caused the puncture. Use a sponge and soapy water to help identify the position. If the tyre walls are punctured, they must not be repaired using this method.
3. Select the appropriate sized repair cord for the damaged area, and centre it through the eye of the insertion tool. Push the string down through the hole until you have inserted 2/3 of the string.
Withdraw the insertion tool in a single motion. The tip of the tool has been designed to separate and release the cord as it is withdrawn.
4. Trim off the excess cord with the knife provided. Inflate the tyre to the recommended pressure. Check the repaired tyre with soapy water to ensure that the hole has been sealed correctly prior to remounting the wheel.

If you have any further questions or enquiries regarding the use of this product, please contact the Kogan.com customer support team.