



## Indoor & Outdoor Mosquito Fan Trap PTMOSQTRAPA Quick Start Guide

### Features

Mosquitoes can detect the location of people even in the dark by sensing carbon dioxide and body heat. They are also highly sensitive to ultraviolet light. Using these behaviours, this trap acts as a decoy, then traps the mosquitoes. The trap works both indoors and outdoors.

### Usage

1. Place bait into the bait holder, then hook the bait holder into one of the small capture windows at the top of the trap.


2. For best results, make sure the top hood is firmly attached. That will keep the mosquito flight concentrated into the optimal position for capture.

3. Plug the trap into a power source.

4. Turn the switch on, and the trap will now be working.

5. For best results, position the traps approximately 30cm from the ground, in a sheltered area known to harbour mosquitoes. The trap is designed to function continuously for 24 hours a day.

6. To empty the trap, turn the unit off and unplug from the power socket. Unscrew the unit and remove the the capture net. As some mosquitoes may still be alive, cover the trap with a cloth or towel before removing the net.




## Precautions

- Do not move the product while it is working.
- Do not put your fingers into the trap while it is switched on.
- When cleaning, turn product off first.
- Do not let children touch product at any time.
- If an accident occurs, dial 000 immediately.
- Do not use near water.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, unless they are being given supervision or instruction concerning the use of the appliance by a person who is responsible for their safety.
- Children should be supervised at all times to ensure they are not playing with the appliance.
- If the supply cord is damaged, then it must be replaced by a Kogan technician.


## Maintenance

### Cleaning the mosquito trap


Turn off the trap and pull the power plug from the wall socket before cleaning.



Take out the safety net. Clean the mosquito trap from the bottom to the top. Firstly turn the base anti-clockwise and separate unit. Take out the **screen window rubber**, then pull out the **screen window**, and clean the screen window with a brush, as shown to the left.




Taking the central fan section, unscrew the screws that are situated around the unit, then separate the two sections from each other.



Clean the inside of the central fan unit with the brush. You may also wipe the sections down with a piece of wet cloth.

## Replacing the light tube



Remove the top light section and lay it upside down. Give the light tubes a half turn, at which point they can be lifted out. Press the new replacement tubes into the slots and give a half turn in the opposite direction to lock it into position.

After any cleaning, be sure to let all parts air dry, then reassemble the unit by reversing the steps above.

**If you have any questions or concerns using this product, please contact the Kogan customer support team.**