

LED ALARM CLOCK (4 in 1)

KALEDALMCKA

User Manual

Thank you for buying the Kogan LED alarm clock.
This handy clock allows you to set an alarm to wake you up, plus acts as a calendar with birthday reminder function and local temperature.

Functions

- Blue LED Backlight
- LCD Clock with Calendar
- Digital Thermometer
- Alarm with Music / Snooze Function
- Chronograph Countdown Timer
- Music Player
- Birthday Reminder with Birthday Song

Basic Operation

1. Insert 3 x AAA batteries to start the unit. At this time, music will play and the LCD display will show- 12:00 1/1 THU
2. In normal mode, press the MODE key to show the following functions in sequence: Normal Mode → 12Hr/24Hr → Alarm → Birthday Reminder → Timer.
3. In normal mode, press the MODE key once to enter into 12Hr/24Hr mode. Press UP/DOWN to switch over between the two different time display formats. Press the SET key and UP/DOWN to set the time and date.
4. In normal mode, press the MODE key two times to enter Alarm mode. Press the SET key and UP/DOWN to set the alarm time, then choose between 7 different alarm songs or 2 different “DiDi” style sounds. Press SET once more to close the alarm function.
When it is time for the alarm to sound, it will play for 1 minute continuously. If the snooze function is on, the alarm will ring one time every 3 minutes, repeating 4 times in sequence.
5. In normal mode, press the MODE key three times to get into Birthday Reminder mode. Press the SET key and UP/DOWN to set the time and date. Press the SET key again to close the Birthday Reminder function. When the preset time arrives, the Birthday song will play for 5 minutes.

6. In normal mode, press the MODE key four times to start Timer mode. Press the SET key and UP/DOWN to set the countdown time ranging from 23:59 hr to 00:00hr. When the timer arrives at 0:00:00, it will ring for 1 minute, while the display of 0:00:00 will remain blinking. Press any key to stop the alarm.
7. In normal mode, when ALARM displays on the upper area of the LCD display, press the UP key to open or close the SNZ function.
8. In normal mode, press the DOWN key to open or close the music playing mode, allowing for 7 different songs to be played.
9. In normal mode, press the SET key to change temperature display between °C/°F formats.
10. In the above mentioned operations, if no key is touched for 1 minute, the clock will return to normal mode.
11. Press the LIGHT button to activate the blue backlight, which will remain lit for 3 seconds.
12. The unit uses 3 x AAA batteries. Please replace the batteries if the screen display is faded or not clear.

Note: the unit does not contain any user serviceable parts. If there is an issue with your alarm clock, please contact the Kogan customer support team. Keep unit away from liquids and direct sunlight. Any misuse or tampering with the product will void the warranty. Kogan is not responsible for any damage or injuries caused by misuse of the product.