


# zmodo™

QUICK  
START GUIDE  
SMART WIRELESS HOME CAMERA



## 1 Quick setup guide

Congratulations!  
Thank you for purchasing our product, and welcome to a smarter world.

### ● Setting up your camera

Follow the instructions to set up your camera. To get started, all you need is a smartphone and WiFi:

- 1 Connect your Android™ phone or iPhone® to the WiFi network that you want your camera to use. Make sure that you know the password to connect to this network.

System Requirements: Android™ (v.2.3 or newer), or iPhone®, iPad®, iPod touch® (v6 or newer), a password-protected 2.4GHz WiFi network.

- 2 Download and install the 'MeShare' app from Google Play™ or the App Store™. Launch the app and sign up for a free MeShare account.



MeShare



- 3 Log in and press the + Add Device option located on the bottom of the screen. Follow the on-screen instructions to complete your setup!

## 2 Recording & Live view

### ● Now compatible with MeShare!

We have partnered with MeShare to bring you optional cloud services! The MeShare Cloud Service (MCS) allows you to:

- Create and save video clips from your recordings.
- Access your playback footage and clips from any location with Internet connection.

- Share recorded footage and clips with family and friends.
  - Access more smart features in the future!
- Visit [www.meshare.com/cloud](http://www.meshare.com/cloud) for more information on plans and features.

### ● MeShare Web App

You can also view your device on any computer using MeShare's free web app. Simply use your Zsight user-name and password and log in to [user.meshare.com](http://user.meshare.com).

## 3 Troubleshooting

- **Solid green**  
The camera is powering on.
- **Blinking green**  
The camera is ready for SmartLink setup.
- **Solid blue**  
The camera has successfully connected to the WiFi network.
- **Blinking blue**  
The camera is connecting to the WiFi network. Please do NOT turn off or unplug the camera.
- **Solid red**

### The camera can't connect to the WiFi. Why?

You may have entered the password incorrectly. Try re-entering your WiFi password.

You may not have a working internal connection. Check to see if your router is connected to the Internet. Try resetting your camera by pressing the reset pinhole on the back of the camera. Hold the button until the light turns blinking green. Then begin the setup procedure again.

.....  
**Having difficulty?** For more instructions, troubleshooting, support information, our knowledge base, the community forum, and other resources, please visit:

<http://www.zmodo.com/supports>

## 4 Connect with us!

Like us on Facebook.com/Zmodo Scan the QR-code below!



Follow us on Twitter @Zmodo Scan the QR-code below!



Android is a trademark of Google Inc. Google Play is a trademark of Google Inc. Apple, the Apple logo, and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.