

Bellezza 2000W Ionic & Ceramic Hair Dryer

BZINCRHRDRY

Quick Start Guide

SAFETY NOTICES

- Please read these instructions carefully and keep a copy safe for future reference.
- Please make sure the power rating of the hair dryer matches the power rating of your electrical outlets.
- Unplug the hair dryer prior to cleaning the unit. Never use water or detergents to clean the hair dryer. Wipe it with a soft dry cloth.
- When unplugging the hair dryer, be sure to hold the plug to pull it out. Never pull the plug out by pulling on the cord.
- Do not use the device in a wet environment such as a humid wet bathroom, changeroom or swimming area.
- Hold the device by the handle only during use. Avoid contact with the main body of the hair dryer as unit will heat up rapidly and could burn you.
- Keep the hair dryer out of the reach of children or the infirm.
- Don't use the hair dryer near flammable items, such as paper.
- The electric cord is not designed to withstand high temperatures. Do not wrap the cord around the hair dryer for storage after use.
- Keep the air intake/output grille clean to avoid damage.
- Turn the power button to the "O" position after use, then unplug the power plug. Leave the unit to cool down completely before you store it in a dry, cool place.
- Turn off the unit and unplug it immediately if there is a strange smell or smoke coming out of the unit.
- Never reach into water to retrieve a dropped electrical device. Instead turn the power supply off at the wall and unplug it completely before lifting the unit out of the water by the cord. Be sure to contact the Kogan customer support team for further advice regarding the damaged hair dryer.

PRODUCT LAYOUT

- 1: Air outlet grille
- 2: Rear cover and filter
- 3: Speed switch (O-Off, I-Low Speed, II-High Speed)
- 4: Temperature switch (O-Cold Air, I-Medium Heat, II-High Heat)
- 5: Cold shot button
(The cold shot button gives a blast of cool air when the button is depressed. Once the button is released, hot air will resume.)
- 6: Unit Housing
- 7: Hang-up loop
- 8: Anti-shock rubber
- 9: Handle

