



BEFORE USE

- Please check that your portable device supports wireless charging before use.
- Please ensure your device is correctly aligned within the charging zone during use.
- Refrain from using any electronic devices around wet areas or with wet hands.

INSTRUCTION

- Plug the charger into a mains power outlet. The indicator light will then turn on.
- Place your wireless charging enable device onto the charging pad, centered on the pad logo.
- Use charging cables where required, to connect devices to the spare USB ports.
- Devices can be placed between the slots during charging, for better space management.
- Remove from mains power during inactive use and store in a cool dry place.



GETTING TO KNOW YOUR WIRELESS CHARGER

1	USB ports
2	Wireless charging pad
3	
4	Vertical storage / Indicator light
5	Mains Power Cable

Specification: Dimension: L220 x W147 x H78 mm, Weight: 560g
 Voltage Input: 100-240Vac 45W, Voltage output (USB): 5V 2A (Max)
 Voltage output (Wireless): 5V 1A (Max)

Warranty Against Defects

Laser Corporation Pty Ltd ("Laser") warrants your new product to be free from defects in materials and workmanship for 12 months, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. The benefit of this warranty is in addition to your rights under the Australian Consumer Law and to other rights and remedies of the consumer under a law in relation to the goods or services to which the warranty relates.

Through a network of retailers and resellers, Laser will provide you with your choice of a repair, exchange (where possible) or refund (**within Dead on Arrival period**) for this product if it becomes defective within the warranty period. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse, normal wear and tear, neglect or improper storage. Please retain your receipt as proof of purchase.

How to make a product warranty claim:

Step 1: Find your receipt which proves the date of purchase. Where the date of purchase cannot be verified, your place of purchase or Laser will make an assessment based on the date of manufacture, the condition of the Laser product and the type of defect.

Step 2a): Contact your place of purchase. They will assess the nature of the fault and repair, replace or refund the product as per their store refund or warranty policy. Step

Step 2b): If your place of purchase cannot be contacted, then you can contact Laser Customer Service with details of your defective Laser Product Phone (02) 9870 3388; or Email: service@laserco.com.au or online www.laserco.com.au/warranty (click on "Consumers (End Users)"). Our business address is: Unit 1/6-8 Byfield Street, North Ryde, NSW 2113.

Step 3: Laser will issue you with a Return Authorisation (RA) number within 48 hours. When requested, send us the defective product and a copy of your receipt. Laser will cover the cost of the return delivery.

Step 4: Wait for us to contact you. Once we have received your defective Laser product for inspection, we will inform you of our assessment of your claim within 7 days. When we contact you, we will firstly let you know whether you have a valid claim under this Warranty, and if so, we will inform you whether your defective Laser product will be replaced or repaired, together with the number of days you can expect to wait to receive your replaced or repaired Laser product.

Step 5: For further details on warranty cover and returns, please check [Terms and Conditions for Warranty Returns](#) section at www.laserco.com.au/warranty (Consumers Section).

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.